

I



D Für die Installation und für den Betrieb der Leuchten sind die nationalen Sicherheitsvorschriften zu beachten.

F Pour l'installation et le fonctionnement des luminaires il est impératif de respecter les normes nationales de sécurité en vigueur.




GB Please note national safety instructions for installation and operation of this luminaire.

PL W celu prawidłowej instalacji i poprawnego działania oprawy należy przestrzegać krajowych przepisów bezpieczeństwa.

E Para la instalación y la puesta en funcionamiento de las luminarias deben observarse las normas nacionales de seguridad.




II




III

	MAXI-LSQ 60x...
	MAXI-LSQ 75x...
	MAXI-LSQ 100x...
	MAXI-LSR 60x...
	MAXI-LSR 75x...
	MAXI-LSR 100x...



IV



V

3x 9

3x 10

	mm ²	A
sol.	0,5-1,0	9
	0,5-2,5mm ²	1,5-2,5

	∅	A
	0,8-1,2	9
max. ∅1,8mm	1,3-1,8	12

11

RIDI

AC 230-240V/50-60Hz

VI

CLICK

12

13

14

4x


VII

15

16

RIDI

MAXI-D-GTR-LED
Montageanleitung



RIDI Leuchten GmbH
Hauptstrasse 31 - 33
D-72417 Jungingen
Tel.: 07477/872-0
Fax.: 07477/872-48
eMail: info@ridi.de
Internet: www.ridi.de