





BET-EDLQ 235	210	195	450	375	175
BET-EDLQ 195	170	160	450	375	162
BET-EDLQ 150	125	150	450	375	125
Typ	BA	H	L	B	C






~~EDLQ 195/ 3000~~
~~EDLQ-235/ 3000-4000~~



BET-EDLQ 235	210	195	450	375	175
BET-EDLQ 195	170	160	450	375	162
BET-EDLQ 150	125	150	450	375	125
Typ	BA	H	L	B	C




~~EDLQ 195/ 3000~~
~~EDLQ-235/ 3000-4000~~



RIDI


BET.- EDLQ 150-235 Montageanleitung



RIDI Leuchten GmbH
Hauptstrasse 31 - 33
D-72417 Jungingen
Tel.:07477/872-0
Fax.:07477/872-48
eMail:info@ridi.de
Internet:www.ridi.de


31/14

MON6170



RIDI

BET.- EDLQ 150-235 Montageanleitung



RIDI Leuchten GmbH
Hauptstrasse 31 - 33
D-72417 Jungingen
Tel.:07477/872-0
Fax.:07477/872-48
eMail:info@ridi.de
Internet:www.ridi.de

31/14

MON6170

